




Department of Engineering Technology



## Computer Applications In Engineering Technology



**MT-369**

Laboratory Supplement  
To The  
“Learning Mastercam X7” Text Book

STUDENTS NAME: .....

Prepared by Prof. J Goldenberg



# DEPARTMENT OF ENGINEERING TECHNOLOGY

## Computer Applications in Engineering Technology **MT-369**

*3 Credits, 2 Class Hours, 3 Lab Hours*

**TEXT:** *Learning Mastercam Mill 7 Step by Step in 2D* by J.V. Valentino and J. Goldenberg, Industrial Press, 2014; Laboratory Manual by J. Goldenberg.

**INSTRUCTOR:** Prof. J. Goldenberg

## Course Outline

WEEK	TOPICS
1	<b>INTRODUCTION TO CAD/CAM/CIM</b> <ul style="list-style-type: none"><li>◆ Mastercam X5 CNC software</li><li>◆ System requirements</li><li>◆ Software installation</li><li>◆ The process of generating a Word Address program</li></ul>
2	<b>MASTERCAM X SETUP PROCEDURES</b> <ul style="list-style-type: none"><li>◆ Types of files created by Mastercam X5</li><li>◆ Starting the Mastercam X5 Design package</li><li>◆ Description of the Mastercam X5 Mill Main interface Window</li><li>◆ Explanation of Gview, View, WCS, Cplane and Tplane terms</li><li>◆ Short-cut keys for entering commands</li></ul>
3	<b>CREATING 2D GEOMETRY</b> <ul style="list-style-type: none"><li>◆ Generating the CAD model</li><li>◆ Point construction</li><li>◆ Line construction</li><li>◆ Arc construction</li><li>◆ Rectangle construction</li></ul>

- 4      **CREATING 2D GEOMETRY (continued)**
- ◆ Polygon construction
  - ◆ Ellipse construction
  - ◆ Geometric letter construction
  - ◆ Filet construction in
  - ◆ Chamfer construction
  - ◆ Screen Display Management: zoom, pan, fit, repaint, regenerate
- 5      **EDITING 2D GEOMETRY**
- ◆ Deleting/Undeleting Entities
  - ◆ Modifying existing geometry
  - ◆ Using Xform functions
  - ◆ Quiz
- 6      **PRODUCTIVITY TOOLS FOR CREATING CAD FILES**
- ◆ Using Levels to organize information
  - ◆ Checking the CAD Model for dimensional correctness
  - ◆ Using analyze feature to check and edit the CAD model
  - ◆ File conversion with other CAD/CAM programs
  - ◆ Sending Mastercam X files over the internet as an e-mail attachment
- 7      **GENERATING HOLE OPERATIONS IN 2D SPACE**
- ◆ Specifying Drilling on the CAD model
  - ◆ Selecting Drill Cycle parameters
  - ◆ Back plotting and Verifying Hole operations
  - ◆ Panning, Dynamic Rotation and Sectioning within the Verifier
  - ◆ Editing drill toolpath. Postprocessing
- 8      **PROFILING AND POCKETING IN 2D SPACE**
- ◆ Creating a 2D Contour for profiling
  - ◆ Common problems encountered in 2D Chaining
  - ◆ Specifying 2D Contouring Parameters
  - ◆ Specifying Pocket Parameters
- 9      **EDITING MACHINING OPERATIONS**
- ◆ The Operations Manager
  - ◆ Creating, moving, copying, deleting existing operations
  - ◆ Editing existing toolpath
  - ◆ Changing the Chaining order
  - ◆ Expanding and collapsing the Operations Display listing
  - ◆ Quiz

10

**USING TRANSFORM TO CONTROL EXISTING TOOLPATHS**

- ◆ The Transform Toolpath function
- ◆ Translating existing toolpaths
- ◆ Rotating existing toolpaths
- ◆ Mirroring existing toolpaths
- ◆ Converting a “transform” into new geometry and operations

11

**USING A LIBRARY FOR MACHINING OPERATIONS**

- ◆ Advantages of using Mastercam’s Operations Library
- ◆ Saving Operations to the Operations Library
- ◆ Importing Operations from the Operations Library
- ◆ Editing data in the Operations Library
- ◆ Quiz

12

**USING TABS AND WORK OFFSETS**

- ◆ Applications of Mastercam’s Tab function
- ◆ Specifying tab parameters
- ◆ Editing tabs
- ◆ Work Offsets
- ◆ Applying Mastercam to Work Offsets

13

**CUSTOMIZING MASTERCAM X**

- ◆ The Customize Dialog box
- ◆ Customizing Toolbar menus
- ◆ The Toolbar States dialog box
- ◆ Creating customized Drop Down menus
- ◆ The Key Mapping dialog box
- ◆ Quiz


14


**SUMMARY. CLASS REVIEW**


15


**FINAL**














*MasterCam Lab Manual*



		NAME <u>      </u>		DRAWING
		COURSE <u>      </u>	DATE <u>      </u>	



*MasterCam Lab Manual*






MasterCam Lab Manual


$\varnothing 4.0$   
1.0 DRILL. 1 3/8 DRILL. 1.5 BORE. 4 HOLES





*MasterCam Lab Manual*




*MasterCam Lab Manual*







*MasterCam Lab Manual*



MasterCam Lab Manual





*MasterCam Lab Manual*




*MasterCam Lab Manual*

(8) .159 DIA. THRU AS NOTED  
 .23 x 82° CHAMFER DIA.  
 TAP FOR 10-32 THD. THRU







MasterCam Lab Manual




*MasterCam Lab Manual*




*MasterCam Lab Manual*




*MasterCam Lab Manual*





*MasterCam Lab Manual*




*MasterCam Lab Manual*




















## CREATE GEOMETRY IN MASTERCAM

*MasterCam Lab Manual*






## CREATE GEOMETRY IN MASTERCAM




*MasterCam Lab Manual*




MasterCam Lab Manual


*MasterCam Lab Manual*




## CREATE GEOMETRY IN MASTERCAM




*MasterCam Lab Manual*




*MasterCam Lab Manual*




*MasterCam Lab Manual*




MasterCam Lab Manual




MasterCam Lab Manual




*MasterCam Lab Manual*




*MasterCam Lab Manual*





*MasterCam Lab Manual*




*MasterCam Lab Manual*




MasterCam Lab Manual




*MasterCam Lab Manual*








*MasterCam Lab Manual*



**Figure 2-p31**



*MasterCam Lab Manual*

Cycle Name	Operation	Tooling
<b>Stop program. Turn Part Over So That Bottom Face(face-2) Is Up. Re-clamp part from inside</b>		
POC x .875	Rough and finish pockets x .875 deep. Leave .01 for finish cut.	1/8 End Mill
	 	
DRILL_1/4	Center Drill x .166 Deep(2 plcs)	1/8 Center Drill
	Peck Drill Thru(2 plcs)	1/4 Drill
	 	
	<b>Stop program. Turn Part Over So That Top Face(face-1) Is Up. Re-clamp part from outside</b>	
TAP_1/4	Center Drill x .166 deep(4 plcs)	1/8 Center Drill
	Peck Drill thru (4 plcs)	#7(.201) Drill
	Tap thru (4 plcs)	.25-UNC-20 Tap
	.02 Chamfer (12 plcs)	.5 Chamfer tool
	 	

*MasterCam Lab Manual*

**Page APP-42.3**




Table 3-5


Cycle Name	Operation	Tooling
CBORE_1.5	Center Drill x .166 Deep	1/8 Center Drill
	Peck Drill Through	1/2 Drill
	CIRCLE MILL 1Dia x 1.125 Deep	1/2 End Mill
	CIRCLE MILL 1.5 Dia x .5 Deep	1/2 End Mill
POC x .25	Rough and finish pocket.x .25 Deep Leave .01 for finish cut.	1/4 End Mill
POC x .375	Rough and finish pocket x .375 Deep Leave .01 for finish cut.	1/4 End Mill
DRILL_1/4	Center Drill x .166 Deep Peck Drill Through	1/8 Center Drill 1/4 Drill
CON X .5	Rough and finish outside. Leave .01 for finish cut.	1/4 End Mill

MasterCam Lab Manual

Table 3p-8

Cycle Name	Operation	Tooling
<b>Clamp part from inside.</b>		
POC x 1.25	Rough Pocket x 1.25 Deep. Leave .01 for finish cut.	1/2 Stub End Mill
	Finish Pocket	1/4 End Mill
CON x .5	Rough Outside.Leave .01 for finish cut.	1/2 Stub End Mill
	Finish Outside	1/4 End Mill
DRILL_1/2	Center Drill x .166 Deep	1/8 Center Drill
	Peck Drill Through	1/2 Drill
DRILL_7/8	Center Drill x .166 Deep	1/8 Center Drill
	Peck Drill Through	7/8 Drill

Blank: Part blank is a 12.25in OD , 5in DIA ID cylinder x 1.75 in












Figure 3p-15

Cycle Name	Operation	Tooling
<b>Clamp Part From Outside with Top Face(face-1) Up.</b>		
POC x .875	<p>Rough and finish pockets x .875 deep. Leave .01 for finish cut.</p>  <p>Material Removed</p>  <p>After Applying POCx.875</p>	1/8 End Mill
CB-TAP_2	Center Drill x .166 Deep	1/8 Center Drill
	Peck Drill Thru	1/2 Drill
	Circle Mill 1.172 Dia Thru	1/2 End Mill
	Circle Mill 2.25 Dia x .75 Deep	1/2 End Mill
	Tap x .375 deep	1.25-UNF-12 Tap
	 <p>Material Removed</p>  <p>After Applying CB-TAP_2</p>	




view of top of part

view of bottom of part

**Figure 3p-16**

Blank: Part blank is a 4.5in x 3.5in x 1.125 plate.







Table 3p-11

Figure 3p-12

Cycle Name	Operation	Tooling
<b>Clamp part from outside</b>		
DRILL_1/8	Center Drill x .166 Deep(5 plcs)	1/8 Center Drill
	Peck Drill Through (5 plcs)	1/8 Drill
TAP_.073	Center Drill x .1 Deep(10 plcs)	1/32 Center Drill
	Peck Drill x .198 Deep(10 plcs)	#53(.06Dia) Drill
	Tap x .135 Deep(10 plcs)	.073 UNC-64 Tap
CBORE_3/4	Center Drill x .166 Deep(2 plcs)	1/8 Center Drill
	Peck Drill Thru(2 plcs)	1/2 Drill
	Circular Mill 3/4 Dia x .25 Deep(2 plcs)	1/4 End Mill
SLOT x .5	Rough and finish .5 x 1.25 slot. Leave .01 for finish cut.	1/8 End Mill
POC x .25	Rough and finish two pockets. .Leave .01 for finish cut.	1/8 End Mill
<b>Stop program. Re-clamp part from inside</b>		
CON x .5	Rough and finish outside Leave .01 for finish cut.	1/8 End Mill

Blank: Part blank is a 4.75in x 2.75in plate






Figure 3p-5





Figure 3p-6








Figure 2-p33


SECTION A-A








**Figure 3p-14**

**Blank:** Part blank is a 5.5in Dia x 1.375in cylinder



Cycle Name	Operation	Tooling
<b>Clamp part from outside</b>		
TAP_1/2	Center Drill x .2 deep(4 plcs)	#7(7/32) Center Drill
	Peck Drill x 1 deep (4 plcs)	27/64(.422) Drill
	Tap x .8 deep (4 plcs)	.5-UNC-14 Tap
	.05 Chamfer (4 plcs)	.75 Chamfer tool 
<i>MasterCam Lab Manual</i>		
CBORE_1.75	Center Drill x .166 Deep	1/8 Center Drill
	Peck Drill Thru	1/2 Drill
	Circle Mill 1.5 Dia x .5 Deep	1/2 End Mill
	Circle Mill 2.25 Dia x .25 Deep	1/2 End Mill
<b>Stop program. Re-clamp part from inside</b>		
POC x .5	Rough and finish pocket x .5 deep. Leave a 3x3 island. Leave .01 for finish cut.	1/2 End Mill
POC x .5	Rough and finish pocket x .5 deep. Leave a 4.25 Dia island. Leave .01 for finish cut.	1/4 End Mill
CON x .5	Rough and finish outside Leave .01 for finish cut.	1/4 End Mill
TAP_1/4	Center Drill x .166 deep(12 plcs)	1/8 Center Drill
	Peck Drill x .375 deep (12 plcs)	#7(.201) Drill
	Tap x .375 deep (12 plcs)	.25-UNC-20 Tap
	.02 Chamfer (12 plcs)	.5 Chamfer tool 




**Figure 3p-10**


Table 3p-10

**MasterCam Lab Manual**


Cycle Name	Operation	Tooling
<b>Clamp part from outside</b>		
DRILL_3/16	Center Drill x .166 Deep	1/8 Center Drill
	Peck Drill Through	3/16 Drill
TAP_1/4	Center Drill x .166 Deep	1/8 Center Drill
	Peck Drill Through	#7(.201) Drill
	Tap(2 plcs)	1/4 UNC-20 Tap
CBORE_2.25	Center Drill x .166 Deep	1/8 Center Drill
	Drill Thru	1/2 Drill
	Circle Mill 1.5 Dia x .5 Deep	1/2 End Mill
	Circle Mill 2.25 Dia x .25 Deep	1/2 End Mill
POC x .188	Rough and finish Pocket. Leave .01 for finish cut.	1/8 End Mill
<b>Stop program. Re-clamp part from inside</b>		
CON x .5	Rough and finish outside Leave .01 for finish cut.	1/4 End Mill


Blank: Part blank is a 3.75in x 5in plate






**SECTION A-A**








*MasterCam Lab Manual*



Cycle Name	Operation	Tooling
<b>Clamp part from outside in a three jaw chuck</b>		
CBORE-B-_3/8	Center Drill x .166 Deep	1/8 Center Drill
	Peck Drill Through	3/16 Drill
	Bore x .1875 Deep	1/4 End Mill <i>MasterCam Lab Manual</i>
POC x .1875	Rough and finish Pocket. Leave .01 for finish cut.	1/4 End Mill
TAP-B_1/8	Center Drill x .1 Deep	#0(.031Dia) Center Drill
	Peck Drill x .325 Deep	#38(.102Dia) Drill
	Tap x .225 Deep	.125 UNC-40 Tap

Blank: Part blank is a 2.5in x .625in cylinder





**Figure 16.88**  
Valve handwheel

**Figure 16.84**  
Ceiling fan cover







Figure 16.84


Ceiling fan cover





**Figure 16.90**  
Shift link





FILE: PROJ-

CENTER FOR ADVANCED MANUFACTURING STUDIES

MAT: 304 ST STL

SCALE: NONE

DATE:

*Mastercam program*







Figure 16.85  
Blade hub




BLADE HUB




*MasterCam Lab Manual*


	NAME <u>      </u>	DRAWING
	COURSE <u>      </u>	DATE <u>      </u>



*MasterCam Lab Manual*


		NAME <u>  </u> COURSE <u>  </u>	DATE <u>  </u>	DRAWING
--	--	------------------------------------	----------------	---------






*MasterCam Lab Manual*

	NAME <u>  </u>	DRAWING <u>  </u>
	COURSE <u>  </u>	DATE <u>  </u>




*MasterCam Lab Manual*

		NAME <u>  </u>	DRAWING
		COURSE <u>  </u>	DATE <u>  </u>



*MasterCam Lab Manual*

		NAME <u>  </u>	DRAWING
		COURSE <u>  </u>	DATE <u>  </u>




NAME   

COURSE   


MasterCam Lab Manual DRAWING

DATE




1 BASE  
MATERIAL: STEEL  
NO. REQ.: 1

	NAME _____	DRAWING
	COURSE _____	DATE _____




FILLETS & ROUNDS R.13


		NAME _____ COURSE _____	DRAWING _____




		NAME <u>  </u>	DRAWING
		COURSE <u>  </u>	DATE <u>  </u>



		NAME <u>                </u>	DRAWING <u>            </u>
		COURSE <u>              </u>	DATE <u>               </u>




		NAME <u>                </u> COURSE <u>              </u>	DATE <u>            </u>	DRAWING
--	--	--	--------------------------	---------




		NAME _____	DRAWING
		COURSE _____	DATE _____

*MasterCam Lab Manual*




		NAME <u>                </u>	DRAWING
		COURSE <u>            </u>	DATE <u>            </u>




*MasterCam Lab Manual*

		NAME <u>      </u>	DRAWING
		COURSE <u>      </u>	DATE <u>      </u>




		NAME <u>      </u>	DRAWING
		COURSE <u>      </u>	DATE <u>      </u>

FILLETS & ROUNDS R .4




	NAME <u>                </u>	DRAWING <u>            </u>
	COURSE <u>              </u>	DATE <u>              </u>


*MasterCam Lab Manual*



METRIC


		NAME _____	DRAWING
		COURSE _____	DATE _____






MasterCam Lab Manual  
R62 U.O.S.

		NAME _____ COURSE _____	DATE _____	DRAWING
--	--	----------------------------	------------	---------




		NAME <u>                </u>	DRAWING <u>                </u>
		COURSE <u>                </u>	DATE <u>                </u>



*MasterCam Lab Manual*


Ø.250-20UNC


		NAME <u>  </u>	DRAWING
		COURSE <u>  </u>	DATE <u>  </u>



MasterCam Lab Manual


DRAWING	NAME	DATE	COURSE
---------	------	------	--------






MasterCam Lab Manual


COURSE	NAME	DRAWING
DATE		






*MasterCam Lab Manual*

COURSE _____	NAME _____	DRAWING
DATE _____		




*MasterCam Lab Manual*




MasterCam Lab Manual

COURSE _____	NAME _____	DRAWING _____
DATE _____		




*MasterCam Lab Manual*


		NAME _____		DRAWING
		COURSE _____	DATE _____	




*MasterCam Lab Manual*


DRAWING	COURSE	NAME	
	DATE		








		NAME _____	DRAWING _____
		COURSE _____	DATE _____




$3 \times \phi 0.375$   
 $\vee \phi 0.75 \times 70^\circ$   
 EQUALLY  
 SPACED


		NAME _____		DRAWING
COURSE _____	DATE _____			




		NAME <u>  </u>	DATE <u>  </u>	DRAWING
		COURSE <u>  </u>		



COURSE _____	NAME _____	DRAWING
DATE _____		




		NAME _____	DRAWING _____
		COURSE _____	DATE _____




COURSE _____	NAME _____	DRAWING
DATE _____		


*MasterCam Lab Manual*



		NAME <u>  </u> COURSE <u>  </u>	DATE <u>  </u>	DRAWING
--	--	------------------------------------	----------------	---------




*MasterCam Lathe Manual*




BOTTOM VIEW.


DRILL .188 THRU  
CBORE .313 x .188 DP.  
(3 HOLES)



*MasterCam Lab Manual*



		NAME <u>      </u>	DRAWING
		COURSE <u>      </u>	DATE <u>      </u>




Write a plan to machine the part by filling out the table below.

Tool#	Tool description	Operation (what will the tool cut)	Notes
1			
2			
3			
4			
5			
6			
7			

### MasterCam Lab Manual

For feeds and speeds use material 6061 Aluminum (the computer will do the calculations)

*Write a Mastercam program to machine the following part:*



*Write a plan to machine the part by filling out the table below.*


Tool#	Tool description	Operation (what will the tool cut)	Notes
1			
2			
3			
4			
5			
6			
7			

*MasterCam Lab M*

*For feeds and speeds use material 6061 Aluminum (the computer will do the*

# MASTERCAM ASSIGNMENT #21

*Write a Mastercam program to machine the following part:*




Write a plan to machine the part by filling out the table below.

Tool#	Tool description	Operation (what will the tool cut)	Notes
1			
2			
3			
4			
5			
6			
7			

For feeds and speeds use material 304 Stainless Steel (the computer will do the calculations)


## MASTERCAM ASSIGNMENT #22




Write a plan to machine the part by filling out the table below.


Tool#	Tool description	Operation (what will the tool cut)	Notes
1			
2			
3			
4			
5			
6			
7			


For feeds and speeds use material 6061 Aluminum (the computer will do the calculations)






		NAME <u>      </u>	DRAWING
		COURSE <u>      </u>	DATE <u>      </u>








*MasterCam Lab Manual*


FRONT VIEW

NAME \_\_\_\_\_  
COURSE \_\_\_\_\_


DATE \_\_\_\_\_

DRAWING






2X .25, THRU  
L Ø.50 Ø.125




*MasterCam Lab Manual*

		NAME <u>  </u>		DRAWING
		COURSE <u>  </u>	DATE <u>  </u>	




*MasterCam Lab Manual*

NAME _____	DRAWING _____
COURSE _____	DATE _____




*MasterCam Lab Manual*

		NAME <u>  </u> COURSE <u>  </u>	DATE <u>  </u>	DRAWING
--	--	------------------------------------	----------------	---------



*MasterCam Lab Manual*


	NAME _____	DRAWING _____
	COURSE _____	DATE _____




NAME \_\_\_\_\_  
COURSE \_\_\_\_\_

MasterCam Lab Manual  
DATE \_\_\_\_\_


DRAWING




MasterCam Lab Manual


NAME       COURSE       DATE       

DRAWING








		NAME <u>      </u> COURSE <u>      </u>	DATE <u>      </u>	DRAWING
--	--	--	--------------------	---------




		NAME <u>                </u> COURSE <u>              </u>	DATE <u>            </u>	DRAWING
--	--	--	--------------------------	---------










	NAME <u>      </u>	DRAWING
	COURSE <u>      </u>	DATE <u>      </u>

*MasterCam Lab Manual*




HEX .68 ACROSS FLATS

*MasterCam Lab Manual*


*MasterCam Lab Manual*

		NAME _____		DRAWING
		COURSE _____	DATE _____	


*MasterCam Lab Manual*




		NAME <u>                </u> COURSE <u>              </u>	DATE <u>              </u>	DRAWING
--	--	--	----------------------------	---------



*MasterCam Lab Manual*



		NAME <u>  </u>		DRAWING
		COURSE <u>  </u>	DATE <u>  </u>	




*MasterCam Lab Manual*

FRONT VIEW


*MasterCam Lab Manual*

		NAME <u>  </u>	MasterCam Lab Manual	
		COURSE <u>  </u>	DATE <u>  </u>	

*MasterCam Lab Manual*



		NAME <u>          </u>	DRAWING <u>      </u>
		COURSE <u>      </u>	DATE <u>      </u>




*MasterCam Lab Manual*

		NAME <u>  </u>	DRAWING
		COURSE <u>  </u>	DATE <u>  </u>

*MasterCam Lab Manual*

*MasterCam Lab Manual*



METRIC

FRONT VIEW


R25 TRP.

DRAWING

NAME


COURSE

DATE



MasterCam Lab Manual

		NAME <u>          </u> COURSE <u>      </u>	DATE <u>      </u>	DRAWING
--	--	--	--------------------	---------




*MasterCam Lab Manual*

		NAME <u>  </u>		DRAWING
		COURSE <u>  </u>	DATE <u>  </u>	


*MasterCam Lab Manual*

*MasterCam Lab Manual*



*MasterCam Lab Manual*

		NAME <u>      </u> COURSE <u>      </u>	DATE <u>      </u>	DRAWING
--	--	--	--------------------	---------



*MasterCam Lab Manual*

		NAME <input type="text"/>		DRAWING <input type="text"/>
		COURSE <input type="text"/>	DATE <input type="text"/>	


*MasterCam Lab Manual*

*MasterCam Lab Manual*


R10 (TYP.)

*MasterCam Lab Manual*

METRIC




		NAME <u>  </u>		DRAWING
		COURSE <u>  </u>	DATE <u>  </u>	



*MasterCam Lab Manual*

		NAME <u>  </u>	DRAWING
		COURSE <u>  </u>	DATE <u>  </u>




*MasterCam Lab Manual*

*MasterCam Lab Manual*


*MasterCam Lab Manual*

		NAME <u>  </u>	DRAWING
		COURSE <u>  </u>	DATE <u>  </u>




MasterCam Lab Manual

		NAME _____	DRAWING _____
		COURSE _____	DATE _____




		NAME <u>  </u> COURSE <u>  </u>	DATE <u>  </u>	DRAWING
--	--	------------------------------------	----------------	---------




*MasterCam Lab Manual*


		NAME <u>          </u> COURSE <u>        </u>	DATE <u>        </u>	DRAWING
--	--	--	----------------------	---------




MasterCam Lab Manual

		NAME <u>  </u> COURSE <u>  </u>	DATE <u>  </u>	DRAWING
--	--	------------------------------------	----------------	---------







		NAME _____ COURSE _____	MasterCam Lab _____ DATE _____	DRAWING Manual
--	--	----------------------------	-----------------------------------	-------------------



MasterCam Lab Manual



		NAME <u>  </u> COURSE <u>  </u>	DATE <u>  </u>	DRAWING
--	--	------------------------------------	----------------	---------




NAME \_\_\_\_\_  
COURSE \_\_\_\_\_

DATE \_\_\_\_\_

DRAWING

*MasterCam Lab Manual*

*MasterCam Lab Manual*



		NAME <u>      </u>		DRAWING
		COURSE <u>      </u>	DATE <u>      </u>	

<b>TL#</b>	<b>TOOL DESCRIPT.</b>	<b>OPERATION</b>	<b>COMMENTS</b>
1	#3 CENTER DRL	C'DRILL (3) HOLES .25 DEEP	
2	3/8 DIA DRILL	PECK DRILL .38 DIA HOLE THRU	
3	9/16 DIA DRILL	PECK DRILL .56 DIA HOLE THRU	
4	1/4 DIA END MILL	PRIFILE OUTSIDE +.01 IN (3) LEVELS + (1) FINISH CUT	

**Fig 2-p2 of the Mastercam Book**

Notes: Material: 6066 Aluminum.

<b>TL#</b>	<b>TOOL DESCRIPT.</b>	<b>OPERATION</b>	<b>COMMENTS</b>
1	#3 CENTER DRL	C'DRILL (1) HOLE .25 DEEP	
2	5/8 DIA DRILL	PECK DRL .625 DIA HOLE THRU	
3	1/2 DIA END MILL	FINISH MACHINING TOP OF THE PART +PRIFILE OUTSIDE +.01 IN (3) LEVELS + (1) FINISH CUT	

**Fig 2-p3 of the Mastercam Book**

Notes: Material: 6066 Aluminum.

<b>TL#</b>	<b>TOOL DESCRIPT.</b>	<b>OPERATION</b>	<b>COMMENTS</b>
1	#3 CENTER DRL	C'DRILL (2) HOLES .25 DEEP	Use these holes as
2	3/8 DIA DRILL	PECK DRL SAME THRU	Entrance holes for (2) openings in the part
3	1/4 DIA END MILL	FINISH MACHINING THE SLOT+ RECTANGLE + PROFILE	PART IS .375 THICK

**Fig 2-p4 of the Mastercam Book**

Notes: Material: 6066 Aluminum.

TL#	TOOL DESCRIPT.	OPERATION	COMMENTS
1	#2 CENTER DRL	C'DRILL (4) .188 HOLES .25 DEEP	
2	3/16 DIA DRILL	PECK DRL SAME THRU	
3	1/8 DIA E/ MILL	FINISH MACHINING THE HEX	USE (5) ROUGHING AND (1) FIN. CUTS
4	½ E/MILL	ROUGH TOP OF PART + PROFILE	
5	¼ E/MILL	FINISH TOP AND PART PRILES	

Fig 2-p5 of the Mastercam Book

Notes: Material: 7075 ALUMINUM

TL#	TOOL DESCRIPT.	OPERATION	COMMENTS
1	#2 CENTER DRL	C'DRILL (1) .34 HOLE + PENTAGON, .25 DEEP	
2	LTR "R" DRILL	PECK DRL SAME THRU	
3	1/8 DIA E/ MILL	FINISH PROFILE THE HEX	USE (5) ROUGHING AND (1) FIN. CUTS
4	½ E/MILL	FINISH TOP OF PART + RGH PROFILE	
5	¼ E/MILL	FINISH PART PROFILE	

Fig 2-p6 of the Mastercam Book

Notes: Material: 7075 ALUMINUM

TL#	TOOL DESCRIPT.	OPERATION	COMMENTS
1	#2 CENTER DRL	C'DRILL (2) .15 HOLE + DOUBLE-D + HEPTAGON, .25 DEEP	
2	#25 DRILL	PECK DRL (2) .15 THRU	
3	.25 E/MILL	C'BORE SAME .25 DEEP	
4	½ DRL	PECK DRILL (THRU) ENTRANCE HOLES TO DOUBLE-D + HEPTAGON	
5	1/8 DIA E/ MILL	FINISH PROFILE THE HEX	USE (5) ROUGHING AND (1) FIN. CUTS
6	½ E/MILL	FINISH TOP OF PART + DOUBLE-D + RGH HEPTAGON & PROFILE	
7	¼ E/MILL	FINISH HEPTAGON + PART PROFILE	

Fig 2-p7 of the Mastercam Book

Notes: Material: 17-4 PH Steel

TL#	TOOL DESCRIPT.	OPERATION	COMMENTS
1	#6 CENTER DRL	C'DRILL (4) HOLES + RECTANGLE ENTRANCE HOLE, .35 DEEP	
2	¾ DIA DRILL	PECK DRL (2) .75 DIA HOLES + rectangle entrance hole	
3	1' DRL	PECK DRILL (2) 1" HOLES	
4	5/8 END MILL	RGH + FIN. PROFILE THE RECTANGLE	
5	¾ DIA E/ MILL	RGH + FINISH PART TOP + PROFILE	

## Fig 2-p8 of the Mastercam Book

Notes: Material: 17-4 PH Steel

TL#	TOOL DESCRIPT.	OPERATION	COMMENTS
1	#2 CENTER DRL	C'DRILL ALL HOLES .25 DEEP	
2	3/8 DRILL	PECK DRILL (2) .38 HOLES THRU	
3	½ DRILL	PECK DRILL (6) .50 HOLES THRU	
4	17/32 DRILL	PECK DRILL .53 & 3. HOLES THRU	
5	11/16 DRILL	PECK DRILL .68 HOLE THRU	
6	½ END MILL	PRIFILE 3" HOLE & THE OUTSIDE	USE 3 ROUGHING AND 1 FINISHING PASS
7			

## Pg 1 of the lab manual exercise.

Notes: Part thickness is .75.

Material: 17-4 PH Steel.

TL#	TOOL DESCRIPT.	OPERATION	COMMENTS
1	#2 CENTER DRL	C'DRILL ALL HOLES .25 DEEP	
2	¼ DRILL	PECK DRILL (6) .25 HOLES THRU	
3	½ DRILL	PECK DRILL (4) .50 HOLES THRU	
4	½ END MILL	PRIFILE SLOTS	

## Pg 9 of the lab manual exercise.

Notes: Material: 6066 Aluminum.

TL#	TOOL DESCRIPT.	OPERATION	COMMENTS
1	#2 CENTER DRL	C'DRILL ALL HOLES .25 DEEP	
2	½ DRILL	PECK DRL (4) .50 HOLES TO .5 DEPTH	
3	½ END MILL	PRIFILE OUTSIDE	USE 3 ROGHING (+.01)& 1 FINISHING PASSES

## Pg 10 of the lab manual exercise.

Notes: Material: 7075 ALUMINUM

TL#	TOOL DESCRIPT.	OPERATION	COMMENTS
1	#2 CENTER DRL	C'DRILL ALL HOLES .25 DEEP	
2	½ DRILL	PECK DRL (4) .50 HOLES THRU	
3	¾ END MILL	PRIFILE INSIDE POCKET & OUTSIDE	

## Pg 11 of the lab manual exercise.

Notes: Material: 303 STL STEEL

TL#	TOOL DESCRIPT.	OPERATION	COMMENTS
1	#2 CENTER DRL	C'DRILL ALL HOLES .25 DEEP	
2	#7 (.201dia) DRL	PECK DRL ALL HOLES THRU	
3	¼-20 TAP	TAP ALL HOLES THRU	
4	½ C'SINK	C'SINK ALL HOLES TO .375 DIA	

## Pg 16 of the lab manual exercise.

Notes: Material: 6066 Aluminum.

TL#	TOOL DESCRIPT.	OPERATION	COMMENTS
1	#2 CENTER DRL	C'DRILL ALL HOLES .25 DEEP	
2	3/8 (.375 ) DRL	PECK DRL ALL HOLES THRU	
3	½ C'SINK	C'SINK ALL HOLES TO .5 DIA	
4			

## Pg 19 of the lab manual exercise.

Notes: Material: 6066 Aluminum.

TL#	TOOL DESCRIPT.	OPERATION	COMMENTS
1	#2 CENTER DRL	C'DRILL (4) HOLES .25 DEEP	
2	13/32 DRILL	PECK DRL (4) .406 HOLES THRU	
3	17/32 FLAT DRL	C'BORE .531 DIA TO .406 DEPTH	Use 2 sec fo the cycle
4	½ END MILL	COMPLETE POCKET	USE 1 ROUGHING (+.01)& 1 FINISHING PASSES

## Pg 22 of the lab manual exercise.

Notes: Material: 7075 ALUMINUM

TL#	TOOL DESCRIPT.	OPERATION	COMMENTS
1	#2 CENTER DRL	C'DRILL ALL HOLES .25 DEEP	
2	3/16 DRILL	PECK DRL (3) .1875 HOLES THRU	
3	¼ DRL	DRILL (5) .25 HOLES THRU	
4	¾ END MILL	COMPLETE PROFILE	USE 2 ROUGHING (+.01)& 1 FINISHING PASSES

## Pg 28 of the lab manual exercise.

Notes: Material: 303 STL STEEL.

Part thickness is .75.

TL#	TOOL DESCRIPT.	OPERATION	COMMENTS
1	#2 CENTER DRL	C'DRILL (4) HOLES .25 DEEP	
2	27/64 DRILL	PECK DRL (4) 27/64 HOLES THRU	
3	½-13TAP	TAP (4) ½-13 HOLES THRU	USE THREADING CYCLE
4	3/8 END MILL	COMPLETE (4) SLOTS AS REQUIRED	
5	¾ END MILL	COMPLETE PART PROFILE	

## Pg 38 of the lab manual exercise.

Notes: Material: 303 STL STEEL.

TL#	TOOL DESCRIPT.	OPERATION	COMMENTS
1	#2 CENTER DRL	C'DRILL (4) HOLES .25 DEEP	
2	3/8 DRILL	PECK DRL (2) .375 HOLES THRU	
3	3/8 END MILL	COMPLETE SLOTS AS REQUIRED	MAKE SURE YOUR END MILL IS AT LEAST 1.125 LONG
4	3/4 END MILL	COMPLETE PART PROFILE	USE (3) RGH & (1 ) FINISH PASS

## Pg 39 of the lab manual exercise.

*Notes:* Material: 7075 ALUMINUM.

TL#	TOOL DESCRIPT.	OPERATION	COMMENTS
1	#5 CENTER DRL	C'DRILL (2) HOLES .35 DEEP	
2	½ DRILL	PECK DRL (1) .5 HOLE THRU	
3	¾ DRILL	PECK DRILL (1) .75 HOLE THRU	
4	1/2 END MILL	COMPLETE SLOT AS REQUIRED	MAKE SURE YOUR END MILL IS AT LEAST 1.125 LONG
	5/8 END MILL	COMPLETE PART TOP CONTOUR + PROFILE	USE (3) RGH & (1 ) FINISH PASS FOR CONTOURING

## Pg 40 of the lab manual exercise.

*Notes:* Material: 7075 ALUMINUM.

TL#	TOOL DESCRIPT.	OPERATION	COMMENTS
1	#52 CENTER DRL	C'DRILL (4) HOLES .25 DEEP	
2	¼ DRILL	PECK DRL (4) .25 HOLE THRU	
3	1/2 END MILL	CONTOUR 1.5 DIA HOLE + FINISH POCKET	FOR CONTOURING USE (3) RGH +1 FINISH PASS

## Pg 44 of the lab manual exercise.

*Notes:* Material: 7075 ALUMINUM.

Use 6.25 diameter round stock.

TL#	TOOL DESCRIPT.	OPERATION	COMMENTS
1	1/2 END MILL	COMPLETE INSIDE AS REQUIRED	

## Pg 45 of the lab manual exercise.

**Notes:** Material: 7075 ALUMINUM.

Use 9"dia round stock.

TL#	TOOL DESCRIPT.	OPERATION	COMMENTS
1	#1 CENTER DRL	C'DRILL ALL HOLES .25 DEEP	
2	#38 DRILL	PECK DRILL (12) .101 HOLES	
3	1/8-40 TAP	CUT THREAD (12) HOLES	
4	3/16 DRILL	PECK DRILL (4) .1875 HOLES THRU	
5	3/8 FLAT DRL	C'BORE (4) .375 DIA TO .1875 DPTH	USE 2 SEC. DWELL
6	3/8 END MILL	CUT (4) SLOTS AS REQ-D	
7			

## Pg 46 of the lab manual exercise.

**Notes:** Material: 17-4 PH Steel

Use 2.5 Dia round stock.






QUEENSBOROUGH AT 50  
CELEBRATE ACHIEVEMENT 

Department of Mechanical Engineering Technology

# MT-369

*LABORATORY PROJECTS OUTLINE*





## **REQUIREMENTS FOR SUBMITTING MT-369 PROJECTS**



*You are required to submit a folder with (4) projects:*

- Project#1:** By using Mastercam, design and create a CNC program to machine a part containing different holes (as described in the Lab Manual requirements).
- Project#2:** By using Mastercam, design and create a CNC program to machine a part containing pockets with and without islands (as described in the Lab Manual requirements).
- Project#3:** By using Mastercam, design and create a CNC program to machine a part where you will be using transform to translate, rotate or mirror existing toolpath (as described in the Lab Manual requirements).
- Project#4:** By using Mastercam, design and create a CNC program to machine a part which requires profile milling, pocketing, hole operations. (as described in the Lab Manual requirements).

*Content: each project must include a page for:*

- Program outline;
- Drawing with dimensions;
- Programming code;
- Screen print of the machined part.

**Note:** *you might be asked to present the motion simulation and inspection for all or some of your projects.*

The following format should be followed:

- ✓ *Cover page, which includes:*
  - *The number of the course (MT-369);*
  - *The name of the course (Computer Applications in Engineering Technology);*
  - *Teachers name;*
  - *Your name;*
  - *Semester (Fall, Spring); Year*
- ✓ *Table of Content with page numbers;*
- ✓ *Introduction;*
- ✓ *Content as described above (with page numbers);*
- ✓ *Conclusion;*
- ✓ *Bibliography ( if you used any outside sources for the project);*

**The report should be bound in a folder with a clear front page.**

*In order to receive credit for this class, submit your report  
not later than the last Laboratory class.*

## MT 369 Project #1 outline

By using **Mastercam**, design a part which requires "hole" operations:

1. C'drilling, shallow hole drilling, blind hole and/or deep hole drilling;
2. C'boring, c'sinking, spot facing;
3. Tapping;
4. Reaming;
5. Boring.


There is no limitation to size and shape of the part and the holes.

Your design will have *at list four (4) types of holes*.

The total number of holes should be *at least 24*.

- Get the design approved by your instructor.
- Plan the sequence of machining operations: specify tooling, feeds, and speeds.
- Write a Mastercam program to complete machining the part.
- Verify the tool motion.
- Document your project as required.

### Design example:



### PROCESS PLAN

No.	Operation	Tooling
1	CENTER DRILL X .2 DEEP(ALL HOLES)	1/8 CENTER DRILL
2	PECK DRILL X 1 DEEP(9PLCS)	5/16 DRILL
3	TAP Y .625 -	

## MT 369 Project #2 outline

By using **Mastercam**, design a part which requires external and internal profiling and “pocketing”:


There is no limitation to the size and shape of the part and the pockets.

Your design will have *at least 3 pockets and at least one “window”*.

*Some pockets should be with islands, some without.*

- Get the design approved by your instructor.
- Plan the sequence of machining operations: specify tooling, feeds, and speeds.
- Write a Mastercam program to complete machining the part.
- Verify the tool motion.
- Document your project as required.

### Design example:



### PROCESS PLAN

No.	Operation	Tooling
1	SPOT DRILL X .166 DEEP (4 HOLES)	1/8 SPOT DRILL
2	PECK DRILL THRU(4 HOLES)	1/4 DRILL
3	SPOT DRILL X .125 DEEP (5 HOLES)	1/32 SPOT DRILL(.31-FLUTE LENGTH;1.5-OAL)
4	PECK DRILL X .325 DEEP	1/8 DRILL
5	PROFILE X .5 DEEP LEAVE .01 FOR FINISH CUTS IN XY AND Z	1/4 FLAT END MILL
6	MILL SLOT X .5 DEEP LEAVE .01 -	1/4 FLAT END MILL


## MT 369 Project #3 outline

By using **Mastercam**, design a part which you later will “morph” by editing existing operations into a redesigned part.

There is no limitation to the size and shape of the part and its elements.  
Your design will have *some pockets and some holes*.

- Get the design approved by your instructor.
- Plan the sequence of machining operations: specify tooling, feeds, and speeds.
- Write a Mastercam program to complete machining the part.
- Verify the tool motion.
- Document your project as required.

### Design example:




## MT 369 Project #4 outline

By using **Mastercam**, create a solid model of a part where contouring, pocketing, drilling is required. Don't forget to specify the stock size and material. There is no limitation to the size and shape of the part and its elements.

- Get the design approved by your instructor.
- Plan the sequence of machining operations: specify tooling, feeds, and speeds.
- Write a Mastercam program to complete machine the part.
- Verify the tool motion.
- Generate a word address part program.
- Document your project as required.

### Design example:







***MasterCam Lab Manual***